



PLAN VIEW

500-kV Ductbank Installation
 Within Paved Roads

FL=FOGLINE
 SDW=SIDEWALK
 SHLD=SHOULDER

Source: RW Beck, 2005